

For proper maintenance of your Urbanscape Green Roof System, we recommend securing a maintenance contract with a green roof maintenance company. At the very least, you should follow these maintenance recommendations below.

## Immediately After Installation

- After the Urbanscape Green Roof system is installed, it must be immediately watered until the vegetation and Urbanscape Green Roll is completely saturated.
- Maximum saturated system holds:
  - 25l/m<sup>2</sup> of water for system with 20mm green roll
  - 37l/m<sup>2</sup> of water for system with 40mm green roll
- Urbanscape green roof must be prevented from drying out until the rooting is successful (root penetration through the Urbanscape Green roll).
- Watering is very important for the rooting of vegetation which will enable long-term success and visual aspect of the Urbanscape® green roof.

Example: If the Urbanscape® green roof is installed during a warm dry period, the green roof must be watered on a frequently basis (daily basis) for a period of six to eight weeks, depending on the weather.



Mini rooting of the vegetation into Urbanscape® green roll after one week.



Complete rooting of the vegetation into Urbanscape® green roll after two months.

## Regular Maintenance of Mature Roof

For ongoing maintenance of your mature green roof, we strongly recommend completing and documenting the following work at least twice per year:

- emergency watering, especially for non-irrigated systems and in the event of longer, dry periods combined with high temperatures
- slow release fertilizer application and removal of weeds/in-blown seeds
- replanting empty patches if they occur
- restoring green roof substrate in the case of wind or water erosion
- inspecting and cleaning all drainage points